



## **ASSEMBLY INSTRUCTIONS**

Remove all items from the carton. Verify all pieces before assembly.


## **PARTS LIST**

KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION
1	5	Caster	7	1	Backrest	12	4	Backrest Tight Screw
2	1	Base	8	2	Armrest	12	2	Backrest Tight Screw
3	1	Seat Post Cover	9	2	Arm Width Adjustment	13	<u> </u>	+Washer
4	1	Seat Post			Knob + Washers	14	1	M5 Size Allen Wrench
5	1	Mechanism	10	2	Arm Bracket			
6	1	Seat	11	4	Mechanism Screw			









## **MECHANISM INSTRUCTIONS:**

- (A) SEAT HEIGHT ADJUSTMENT:
  - Pull lever up and downward. Release lever when desired position is reached.
- (B) BACK TILT ADJUSTMENT:

Turn the lever up, move backrest to tilt. To lock in position, turn lever down.

- (C) TILT TENSION ADJUSTMENT KNOB: Rotate knob clockwise / counterclackwise to adjust tilt tension based on body weight.
- (D) TILT LOCK

Lock and realesae switch of synchronized tilt with 3-position stop.

## PREVENTIVE MAINTENANCE AND WARNING!

ASSEMBLY INSTRUCTIONS.

- USE THIS PRODUCT ONLY FOR SEATING ONE PERSON AT A TIME. DO NOT USE THIS CHAIR AS A STEP STOOL / LADDER. DO NOT SIT ON ANY PART OF THE CHAIR EXCEPT THE SEAT. DO NOT USE CHAIR ON UNEVEN FLOOR SURFACES. DO NOT USE CHAIR UNLESS ALL BOLTS, SCREWS AND KNOBS
- EVERY SIX MONTHS, PLEASE MAKE SURE ALL BOLTS, SCREWS AND KNOBS ARE FULLY TIGHTENED TO ENSURE STABILITY.

- IF ANY PARTS ARE MISSING, BROKEN, DAMAGED OR WORN, STOP USE OF THE PRODUCT UNTIL REPAIRS ARE MADE USING FACTORY AUTHORIZED PARTS.
  DISPOSE OF PACKAGING PROPERLY. PLASTIC BAG IS NOT A TOY. DO NOT USE PLASTIC BAG AS HEAD COVERING IT MAY CAUSE SUFFOCATION.
  FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY. NOTE: SOME SCREWS MAY BE PREASSEMBLED. IF PREASSEMBLED, IGNORE